

1x



2x



2x



China RoHS

按照 SJ/T11364《电子电气产品有害物质限制使用标志要求》的规定,现将该产品的环保信息向您告知如下:

零件名称	产品中有害物质或受限物质的名称及含量					
	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (Cr(VI))	多溴联苯 (PBBs)	
塑料: Plastic Part	0	0	0	0	0	0
焊料: Solder	0	0	0	0	0	0
铜合金: Cu	0	0	0	0	0	0
二极管: Diode	0	0	0	0	0	0
晶体振荡器: Crystal	0	0	0	0	0	0
电阻: Resistor	X	0	0	0	0	0
电容: Capacitor	0	0	0	0	0	0
电感: Inductor	0	0	0	0	0	0
连接器: Connector	0	0	0	0	0	0
印刷板: PCB	0	0	0	0	0	0
焊锡: Solder	0	0	0	0	0	0
阻焊剂: Ink	0	0	0	0	0	0
线材: Wire Harness	0	0	0	0	0	0

0: 表示该有害物质在规定的材料和工艺中的含量均符合 GB/T 2657 标准规定的限量要求以下。
 X: 表示该有害物质至少在该部件的某一规格材料中的含量符合 GB/T 2657 标准规定的限量要求。
 * 表示: "X" 表示有害物质符合欧盟 RoHS 法规。超过 GB/T 2657 规定限量的部件将在表格的豁免条款。

(欧盟关于电子电气设备中限制使用某些有害物质的 2011/65/EU 号指令)

产品标志:

(1) 产品标志上的环保使用期限(Ecofriendly Use Period, EUP)标识表示在此期间内,在产品使用寿命内,产品中所含的有害物质成分不会发生泄漏和挥发。因此,把产品的使用不当导致任何严重的环境污染,任何人伤害或财产损失,同时,不引起任何回收义务转移或责任转移。

(2) 标签上带有回收标志的产品是可以回收的,不应随意进行处理。



www.elotouch.com

Quick Installation Guide

Barcode Scanner

Revision B
P/N E202955

Elo Touch Solutions Technical Support

Online self-help:
www.support.elotouch.com

North America

800-ELO-TOUCH
Tel +1 408 597 8000
Fax +1 408 597 8050
EloSales.NA@elotouch.com

Europe

Tel +32 (0)16 70 45 00
Fax +32 (0)16 70 45 49
elosales@elotouch.com

Asia-Pacific

Tel +86 (21) 3329 1385
Fax +86 (21) 3329 1400
EloAsia@elotouch.com

Latin America

Tel 786-923-0251
Fax 305-931-0124
EloSales.LATAM@elotouch.com

The information in this document is subject to change without notice. Elo Touch Solutions, Inc. and its Affiliates (collectively "Elo") makes no representations or warranties with respect to the contents herein, and specifically disclaims any implied warranties of merchantability or fitness for a particular purpose. Elo reserves the right to revise this publication and to make changes from time to time in the content hereof without obligation of Elo to notify any person of such revisions or changes.

No part of this publication may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language or computer language, in any form or by any means, including, but not limited to, electronic, magnetic, optical, chemical, manual, or otherwise without prior written permission of Elo Touch Solutions, Inc.

Elo (logo) and Elo Touch Solutions are trademarks of Elo and its Affiliates.

© 2017 Elo Touch Solutions, Inc. All rights reserved.



Installation

Please go to www.elotouch.com/support to verify you have the latest drivers before installing this device.

Notes:

1. Place barcode a minimum of 40mm away from the scanner window for proper operation.
2. Software triggering of scanner not available on E267080.



Select the location to mount the barcode scanner. Some mounting locations not available on all systems.



Remove the selected peripheral cover from the display head to expose the peripheral bay.



Gently press the barcode scanner into the peripheral bay making sure the connector is mated.



Install the 2 flat head screws included with the kit.

Do not rotate the barcode scanner head without installing the screws or damage may occur.



Remove the protective film from the included mylar covers and place the covers over the screws.

Adjust the scanner angle as needed.