

校期SZF[1364(电子电气产品有害物质则解使用标志要求)的规定,现存该产品 的环保损息内容各种如下如果您的产品不会在中国地区生产或构模。figures可容格

部件名称	产品中有害物质或元素的名称及含量					
	45 (Pb)	W (Hg)	(Cd)	六价格 (Cr(VD)	多溴底苯 (PBB)	多溴二苯E (PBDE)
EEE247 Pastic	×	0	0	0	0	0

产品标志 (1) 产品标选上的好码使用周取值svormental Protection Use Period, ERUPM。具卷开 在定期间先在已接得个条件下,点中给查有结构的成功。今次更先是制度处 因此我开始的成功并会是现在何个维约标识的。在每人身态高级对于很失。 而不完全年级现在为各部场底中就说。 ① 格洛上年有河流控制标志的一品是可以现象的不同量直进行选择。

### **Elo Touch Solutions Technical Support**

Online self-help:

www.support.elotouch.com

North America 800-ELO-TOUCH Tel +1 408 597 8000 Fax +1 408 597 8050 EloSales.NA@elotouch.com

Europe Tel +32 (0)16 70 45 00 Fax +32 (0)16 70 45 49 elosales@elotouch.com

**Asia-Pacific** Tel +86 (21) 3329 1385 Fax +86 (21) 3329 1400 EloAsia@elotouch.com

## Latin America

Tel 786-923-0251 Fax 305-931-0124 EloSales.LATAM@elotouch.com

The information in this document is subject to change without notice. Elo Touch Solutions, Inc. and its Affiliates (collectively "Elo") makes no representations or warranties with respect to the contents herein, and specifically disclaims any implied warranties of merchantability or fitness for a particular purpose. Elo reserves the right to revise this publication and to make changes from time to time in the content hereof without obligation of Elo to notify any person of such revisions or changes.

No part of this publication may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language or computer language, in any form or by any means, including, but not limited to, electronic, magnetic, optical, chemical, manual, or otherwise without prior written permission of Elo Touch Solutions, Inc.

Elo (logo) and Elo Touch Solutions are trademarks of Elo and its Affiliates.







www.elotouch.com

## **Quick Installation Guide**

Elo Webcam

Revision B P/N E485251

© 2017 Elo Touch Solutions, Inc. All rights reserved.

# Installation

Please go to www.elotouch.com/support to verify you have the latest drivers before installing this device.

**Caution:** Damage to the IDS Display can occur if the webcam is inserted with too much force. If the webcam connector does not mate with gentle insertion force, remove the webcam and reposition before gently trying to insert again.



Select the location to mount the webcam. Elo recommends the top location in either portrait or landscape orientation.

Note: The webcam will function in any location on the IDS Display but the video will need to be rotated using software if the webcam is not mounted on the top.




Install the 2 flat head screws included with the kit.

Do not adjust the webcam tilt without installing the screws or damage may occur.




Remove the selected peripheral cover from the IDS Display.



Adjust the forward/back position of the webcam by loosening the two highlighted screws with the included 3mm allen wrench and sliding the webcam head forward as needed. Tighten screws when done.



Gently insert the webcam into the peripheral bay taking care to ensure the connector mates properly.



Adjust the tilt angle of the webcam by loosening the highlighted screw and lifting up on the back of the webcam head. Tighten screw when done.